

Installation Instructions

Tools Required

Tape and utility knife.

Pre-installation

Glass surface must be clean. Use soap and water only, no solvents or Windex Glass Cleaner. Glass must be completely dry. Use lint-free cloth or brown industrial paper towels to dry the glass.

Temperature of glass should be between 50° - 85°. In extremely cold weather apply graphic vinyl in a garage or during the late afternoon, after windows have warmed up. Applying graphic vinyl to glass that is too cold may adversely affect the adhesion of the vinyl. Vinyl that has been stored in extremely cold conditions can become brittle. Allow the vinyl to warm up before installing to prevent it from cracking. In extremely warm weather apply vinyl in shaded area or during early morning, when glass surface is still cool. Applying graphic vinyl to glass that is too hot can cause the vinyl to stretch.

Basic Installation Instructions

1. Position graphic vinyl on window lightly taping top corners to vehicle. Step back a few feet and determine if graphic is in correct position, centered, text running level and not extended outside of window glass area. Adjust graphic vinyl as required and re-tape. You may repeat this step several times to insure correct positioning of graphic.

2. With graphic vinyl in correct position and top corners taped down attach another piece of tape at the center top, and center bottom of the graphic vinyl to the vehicle.

3. Remove tape from top right corner and gently fold graphic vinyl in half at center, like closing a book (take care not to crease vinyl).

4. Working from the backside center of the graphic vinyl carefully start removing backing liner from the graphic vinyl (remove approximately 12 – 18 inches of backing).

5. Using your hand or a soft plastic squeegee, lightly press the vinyl in place (use caution not to scratch or cut graphic). Working from the center of the graphic to the right outside edge, continue peeling away more of the backing liner and applying light pressure to the vinyl. Once you have reached the right outside edge remove the tape from the left top corner of graphic vinyl and continue the process from the center working towards the left outside of the graphic. Continue in this manner until the backing liner is completely removed and the window graphic is in place.

6. Using a utility knife, position the blade tip on the glass and up against the inside edge of window seal trim. Carefully cut away any unneeded portion of the graphics vinyl paying close attention not to cut the rubber window seal.

If you are installing more than one panel, properly align the next graphic in relation to the adjoining panel(s) and follow steps 1 through 6 above.

Note: In the case of graphics that must be seamed together, install the two pieces so that the edges of the film butt against each other, with the holes aligned (don't overlap the two edges of the film).

7. Finally, press the graphic vinyl in place with the palm of your hand or a squeegee. Working from the center of window and working outward in all directions. Be sure to press the edges firmly in place.

Step back and admire your work!

Cleaning and Care

Use soap and water only. No solvent window cleaners. Let air dry or gently use a soft cloth. Spray clean only, no scrubbing or cleaning with a bristle brush. No automatic car washes that use brushes to clean windows.

Do not use on or with:

Rear Window Wipers, Ice Scrapers, Roll Down Windows, or Sliding Glass Windows.

Thank You for your Purchase